DART SERVICE INSTRUCTION

TO AMEND INSTALLATION INSTRUCTIONS D205-634 REV. G AND D204-635 REV. G OR EARLIER, AND INSTRUCTIONS FOR CONTINUED AIRWORTHINESS ICA-D205-634 REV. 4 AND D204-635 REV. 4 OR EARLIER

REF CANADIAN STC: SH96-88 REF FAA STC: SR00563NY REF EASA STC: EASA.IM.R.S.01303

1.0 PURPOSE:

To provide a repair for cracked D2579 saddle spacers in early model D205-634-011 and D204-635-011 skidtubes.

2.0 PROCEDURE:

- 1) Remove the affected skidtube(s) in accordance with ICA-D205-634 / ICA-D204-635 Chapter 32.1. Place on a suitable work surface and remove aft cap(s) in accordance with ICA-D205-634 / ICA-D204-635 Chapter 32.8.
- 2) Remove paint, old sealant, etc in the affected area.
- 3) Slowly drill out one side of the damaged spacer(s) to Ø 0.500" using the provided step drill while ensuring not to flare the end of the spacer. Slowly drill out the other side, then deburr holes to remove all sharp edges.

Note: The spacer will be pushed slightly out of the skidtube by the step drill once the final side is drilled out.

- 4) Chamfer spacer holes to 0.050" X 45° on both sides of the skidtube.
- 5) Touch up holes with chemical conversion coating in accordance with MIL-DTL-5541.
- 6) Install D4981-1 spacer using Magnobond 6398 or ProSeal 890 (Ref. AMS-S-8802), allow adequate time for sealant to cure, and grind flush.
- 7) Touch up finish with one coat of MIL-P-85582 or MIL-P-23377 primer, and 2-3 coats of MIL-C-83285 Polyurethane paint to match original finish as required.
- 8) Remove all swarf from the interior of the skidtube and reinstall aft cap in accordance with ICA-D205-634 / ICA-D204-635 Chapter 32.8. Reinstall skidtube(s) on aircraft per ICA-D205-634 / ICA-D204-635 Chapter 32.2.

3.0 PARTS LIST:

QTY -011	PART NUMBER	DESCRIPTION	
Х	DSI 9675-011	CROSSBOLT SPACER REPAIR KIT	
8	D4981-1	SPACER	
1	IRWIN 1T UNIBIT	STEP DRILL	

4.0 WEIGHT AND BALANCE:

There is a negligible weight and balance change associated with this modification.

CANADA DEPARTMENT OF TRANSPORT AIRCRAFT CERTIFICATION BRANCH DAO # 01-0-01					
BY: D. SHEPHERD (DE # 02)					
DATE: 13.12.15 CERT. NO.: SH96-88 ISSUE NO.: 3					

В	REVISED PROCEDURE			ML	13.12.10	
A	NEW ISSUE			ML	13.11.18	
REV.	DESCRIPTION			BY	DATE	
DESIGN ML			DART AEROSPACE LTD			
DRAWN ML		ML	HAWKESBURY, ONTARIO, CANADA			
CHECH	CHECKED A.V.		DRAWING NO.		REV. B	
MFG. A	PPR.	CAL	DSI 9675		SHEET 1 OF 1	
APPROVED IN		111	TITLE		SCALE	
DE AP	PR.	AL.	SPACER REPAIR KIT		NTS	
DATE	DATE 13.12.10 COPYRIGHT © 2013 BY DART AEROSPACE LTD THIS DOCUMENT IS PRIVATE AND COMPOSITION, AND IS SUPPLED ON THE EXPRESS CONDITION THAT IT IS NOT TO BE USED FOR ANY PURPOSE OR COPIED OR COMMUNICATED TO ANY OTHER PERSON WITHOUT WRITTEN REPRESSON PROM DART AEROSPACE LTD.					